MUST READ BEFORE USE

INSTALLATION GUIDE

UltraScape Flowpoint is a rapid-set, pour and brush-in street grout. Pre-soak, mix, squeegee into the joints, keep moist, then wash off. One product for the whole job, conforming to BS 7533.



15 min	4.25 L	3–5 min	4 min	BS 7533
CURE AT 20°C	WATER PER 25KG BAG	MIXING TIME	WORKING WINDOW	CONFORMS TO

! **Read this guide fully before you start.** Mix only what you can apply in 4 minutes, and try one bag first to gauge your working time.

01 PREPARE & EQUIP

Get the site and your tools ready before opening a bag. Preparation decides the finish.

ESSENTIAL EQUIPMENT

- [x] Long-handle squeegee
- [x] Rubber grouting trowel
- [x] Hose with adjustable spray gun (mist and firm spray)
- [x] 5L measuring jug
- [x] 20L bucket
- [x] Drill with mixing paddle
- [x] Soft broom and stiff broom
- [x] Cloth tape for masking edges without haunch

SITE PREPARATION

- [x] Clear all joints of debris
- [x] Remove every trace of ponded water
- [x] Pre-soak the paving surface and joints
- [x] Keep the area wet until jointing is complete

! **Joints must be free from ponding water.** Do not leave pooled water sitting in the joints.

WEATHER NOTE

COOL TEMPERATURES RETARD. WARM TEMPERATURES ACCELERATE.

Plan batch sizes around the day. In heat, cure times drop fast, so mix less and work quicker.

Talk to us about your project. Prolific Stone, exclusive Australian distributor of UltraScape Flowpoint.

☎ 03 8751 8880 ✉ sales@prolificstone.com.au

02 APPLICATION

STEP 1

MIX

Add **4.25 litres of water** to one 25kg bag, using the measuring jug as your guide. Mix in a 20L bucket for **3 to 5 minutes** until smooth and lump free.

STEP 2

SPREAD & FILL

Apply without delay. Spread and push grout into the joints with the rubber squeegee. Top up any joints that slump, then squeegee as much grout off the surface as possible. **Do not store grout in the bucket.**

STEP 3

KEEP MOIST

Keep the surface moist at all times using a **soft mist spray only**. Never let it dry out during the process.

STEP 4

WASH OFF

Once the grout has hardened sufficiently, clean the paving with a hose and broom. Use high pressure with caution, as it will blow grout from the joints. Leave **no grout on the surface**.



GOLDEN RULES

- ☑ Use the measuring jug: 4.25L per bag
- ☑ Mix only what you can apply in 4 minutes
- ☑ Never remix or add extra water
- ☑ Wash all tools frequently

Talk to us about your project. Prolific Stone, exclusive Australian distributor of UltraScape Flowpoint.

☎ 03 8751 8880 ✉ sales@prolificstone.com.au

03 CURING & SAFETY

Standard smooth curing, rule of thumb. Baseline is 15 minutes at 20°C.

TEMPERATURE	RELATIVE SPEED	APPROX. CURE
5°C	4x slower	~60 min
10°C	2x slower	~30 min
20°C	Baseline	15 min
25°C	2x faster	~7-8 min
30°C	4x faster	~4 min
RULE OF THUMB	**COOL RETARDS**	**WARM ACCELERATES**

SAFETY & PRECAUTIONS

- [x] Wear protective clothing
- [x] Avoid skin and eye contact
- [x] Keep surface moist, fine mist spray only
- [x] Never remix or add extra water
- [x] Wash all tools frequently



ONE PRODUCT. EVERY JOB.

READY WHEN YOU ARE.

UltraScape Flowpoint, exclusive to Prolific Stone in Australia. Talk to us about your project: call **03 8751 8880** or email **sales@prolificstone.com.au**.